

ACCUMULATORE A TAMPONE PS

DIMENSIONI E DISPOSIZIONE RACCORDI

Tabella delle misure secondo disegni [mm]

Tipo	PS 500	PS 800	PS 1000-B	PS 1000-S	PS 1250	PS 1500	PS 2000	PS 2500	PS 3000	PS 4000	PS 5000
H	1760	1910	1950	2120	2200	2190	2280	2170	2645	2290	2790
D1	650	750	850	790	900	1000	1100	1300	1250	1600	1600
D2	850	950	1050	990	1100	1200	1300	1500	1470	1820	1820
Misura di ribaltamento	1800	1965	2020	2180	2270	2280	2380	2350	2780	2520	2945
a	240	265	290	270	295	340	350	400	390	450	455
b	320	345	370	350	375	420	430	480	470	480	500
c	730	790	810	850	900	910	940	920	1080	945	1145
d	1140	1235	1250	1350	1420	1400	1450	1370	1690	1045	1790
e	1550	1680	1700	1850	1940	1890	1960	1810	2295	1870	2370
f	1540	1680	1680	1900	1700	1890	1950	1810	2200	1700	2300
f1	–	–	–	1680	–	–	–	–	–	–	–
g	1150	1170	1170	1170	1170	1280	1370	1360	1460	1170	1600
h	720	725	725	725	725	775	860	880	880	725	950
i	270	350	350	350	350	350	350	400	415	350	350
j	260	325	350	330	335	400	410	450	440	495	505
k	710	770	790	830	880	890	920	890	1050	915	1115
l	1120	1215	1230	1330	1400	1380	1430	1340	1660	1375	1760
m	1430	1535	1550	1740	1800	1760	1830	1670	2155	1725	2225
no	1510	1615	1630	1820	1880	1840	1910	1750	2235	1805	2305
o	1565	1695	1710	1900	1960	1920	1990	1830	2315	1885	2385